

IRA J. BERNSTEIN & ASSOCIATES, INC.

MANUFACTURERS' REPRESENTATIVE & CONSULTANT • FLOOR & WALL COVERINGS

Ambient 2-in-1 Silencer Underlayment Installation

Directions for Installation:

- Underlayment pads are installed prior to floating floors by unrolling and running the underlayment the full length of the room until the entire sub-floor is covered.
- Seams are securely taped together and the overlapping Moisture Guard edges will prevent moisture and dirt from penetrating these seams.
- Install with Blue side down and white side up.
- Unroll with flush side against wall & plastic & overlap on open side.
- Neighboring row's flush side should overlap on top of excess blue plastic of previous row.
- Tape rows together with Duct tape.
- Install flooring once all underlayment is installed and secure.

Bamboo flooring is a natural product; variations in color are to be expected.